


Amplification Taurus

Stomp-Head⁴ silver line



- [1] - INPUT
- [2] - Effect-loop SEND [6,3mm JACK]
- [3] - Effect-loop RETURN [6,3mm JACK]
- [4] - LINE OUTPUT with speaker cabinet simulation
- [5] - Power selector 70Wat/40Wat for 4-8ohm and 50Wat for 16ohm
- [6] - Speaker impedance selector 4/8/16ohm
- [7] - Speakers output
- [8] - EC POWER INPUT and. optionally, voltage selector switch [230V/50Hz or 115V/60Hz]
- [9] - POWER on/off switch
- [10] - CRUNCH control / CLEAN channel
- [11] - BASS control / CLEAN channel
- [12] - MIDDLE control / CLEAN channel
- [13] - TREBLE control / CLEAN channel
- [14] - Volume control / CLEAN channel
- [15] - DRIVE control / LEAD channel
- [16] - BASS control / LEAD channel
- [17] - MIDDLE control / LEAD channel
- [18] - TREBLE control / LEAD channel
- [19] - VOLUME control / LEAD channel
- [20] - BOOST knob regulator (activated by foot-switch)
- [21] - MASTER control
- [22] - LED indicator / CRUNCH-on
- [23] - LED indicator / CLEAN-on
- [24] - LED indicator / LEAD-on
- [25] - LED indicator / BOOST-on
- [26] - Inputs for external controller or a foot-switch: BOOST activating and EFFECT-LOOP bypass
- [27] - Inputs for external controller or a foot-switch: CHANNEL change and CRUNCH activation
- [28] - CRUNCH foot-switch
- [29] - CLEAN / LEAD foot-switch
- [30] - BOOST foot-switch
- [30] - MUTE foot-switch
- [31] - STUDIO/STAGE power reduction - in STUDIO position the power is ten times lower: 4W, 5W or 7W
[Depending on POWER SELECTOR "5" position]
- [32] - Protection - LED indicator