



- [1] - POWER on/off switch
- [2] - Voltage selector 230V/120V
- [3] - EC POWER input
- [4] - Speakers output / impedance: 4-8-16ohm
- [5] - Effect-loop SEND
- [6] - Effect-loop RETURN / PA-input
- [7] - INPUT
- [8] - INPUT GAIN boost +6dB
- [9] - Power selector 60Watt/25Watt
- [10] - BASS control / CLEAN channel
- [11] - MIDDLE control / CLEAN channel
- [12] - TREBLE control / CLEAN channel
- [13] - CRUNCH control / CLEAN channel
- [14] - Volume control / CLEAN channel
- [15] - DRIVE control / LEAD channel
- [16] - BASS control / LEAD channel
- [17] - MIDDLE control / LEAD channel
- [18] - TREBLE control / LEAD channel
- [19] - VOLUME control / LEAD channel
- [20] - LED indicator / CLEAN-on
- [21] - LED indicator / LEAD-on
- [22] - MUTE foot-switch
- [23] - CLEAN / LEAD foot-switch
- [24] - LED indicator / 60Watt or 25Watt
- [25] - PRESENCE mode switch
- [26] - LINE OUTPUT with speaker cabinet simulation
- [27] - Output for external channel selector switch [ON/OFF type switch required]

