


Amplification *Taurus*



1. INPUT - mono 1/4" (jack) > impedance: 1M ohm
2. OUTPUT - stereo/mono 1/4" (jack) > impedance: 1K ohm
3. POWER SUPPLY INPUT - DC 9-12V/polarity supply auto detection
4. DEPTH - determines the degree of CHORUS modulation
5. A-NORMAL-B - three way mode switch
Flanger Modern A - Chorus - Flanger Modern B
6. ENHANCER - level of extended polyphony in low frequency range
7. RATE - controls speed of CHORUS modulation
8. DETUNE - determines the degree of CHORUS and ENHANCER detuning
9. FOOT SWITCH - true-bypass when on the "Off "
10. Effect „ON" indicator