


FRONT PANEL



- [1] - Active bass instrument INPUT [JACK 6.3mm].
- [2] - Passive bass instrument INPUT [JACK 6.3mm].
- [3] - GAIN control - True/Boost.
- [4] - BASS control with MLO-system.
- [5] - Triple BASS - switch to reduce or boost low frequency [DBS-cut/OFF/DBS-boost].
- [6] - MIDDLE control.
- [7] - PUNCH triple switch - High-Punch/off/Low=Punch
- [8] - TREBLE CONTROL with MLO-system.
- [9] - Triple TREBLE - switch to reduce or boost high frequency [CUT/OFF/PRESENCE].
- [10] - VOLUME control.
- [11] - MUTE on/off switch.
- [12] - ON/MUTE indicator.
- [13] - Power amplifier CLIP indicator.
- [14] - STANDBY and PROTECTION indicator.

REAR PANEL



- [1] - Balanced LINE OUTPUT [XLR].
- [2] - SPEAKERS output [combo SPEAKON and 6,3mm JACK].
- [3] - LINE OUTPUT PRE/POST EQ switch.
- [4] - LINE OUTPUT GROUND LIFT switch.
- [5] - POWER switch.
- [6] - EC POWER INPUT socket with AC fuse.