


Amplification Taurus



1. **INPUT** - mono 1/4" (jack)
2. **OUTPUT** - mono 1/4" (jack)
3. **POWER SUPPLY INPUT** - DC 9-12V Polarity supply auto detection/ connector dimensions 5,5x2,1mm.
DC ASSISTANT - protects from loss of signal. Effect switches automatically to the "bypass mode" in case of disconnection or low voltage of DC supply (<6V).
4. **LEVEL**- knob controls overall effect volume
5. **CHRACTER** "Blend knob" between "Vintage" & "Modern" sound.
6. **GAIN** - input gain preamp adjustment.
7. **BASS** - low frequency level control with MLO system.
8. **Triple BASS-switch** to reduce or boost low frequency CUT/OFF/BOOST
9. **TREBLE** - high frequency level control with MLO system.
10. **Triple TREBLE-switch** to reduce or boost high frequency CUT/OFF/PRESENCE
11. **PUNCH** - midrange effectiveness switch.
12. **Footswitch Mode** - bypass/mute footswitch mode selector
 - footswitch mode "Mute" - mutes signal at the output. Usefull when works as a Di-box connected to mixer.
 - footswitch mode „Bypass"- switches between ON and BYPASS. Usefull when works as a effect connected to amplifier.
13. **Footswitch**. If it's turned off true-bypass is active.
14. **OUTPUT - XLR** - mixing console connection (balanced)
15. **Effect „ON"** indicator
16. **Ground lift switch**.