


# Amplification Taurus

## Stomp-Head<sup>1</sup>



- [1] - INPUT
- [2] - Effect-loop SEND
- [3] - Effect-loop RETURN / PA input
- [4] - LINE OUTPUT with speaker cabinet simulation
- [5] - Speakers output / impedance: 4-8-16ohm [auto detect. impedance]
- [6] - DRIVE control / LEAD channel
- [7] - BASS control / LEAD channel
- [8] - MIDDLE control / LEAD channel
- [9] - TREBLE control / LEAD channel
- [10] - VOLUME control / LEAD channel
- [11] - BASS control / CLEAN channel
- [12] - MIDDLE control / CLEAN channel
- [13] - TREBLE control / CLEAN channel
- [14] - VOLUME control / CLEAN channel
- [15] - Power selector 50Watt/25Watt
- [16] - LED indicator of the selected channel
- [17] - CLEAN / LEAD foot-switch
- [18] - AC POWER input. Range: 90-260V / 50-60Hz
- [19] - POWER on/off switch

100W/rms power stage INSIDE

