



- [1] - POWER on/off switch
- [2] - Voltage selector 230V/120V
- [3] - AC POWER input
- [4] - Speakers output / impedance: 4-8-16ohm [auto detect. impedance]
- [5] - EFFECT LOOP connectors [SEND and RETURN]
- [6] - Power selector 90Watt/40Watt
- [7] - INPUT GAIN boost +6dB
- [8] - INPUT
- [9] - Output for external controller
- [10] - LINE OUTPUT with speaker cabinet simulation
- [11] - NORMAL / MIX-MODE selector
- [12] - NOISE GATE control
- [13] - NOISE GATE LED indicator
- [14] - NOISE GATE ON/OFF switch
- [15] - BOOST control
- [16] - BOOST LED indicator
- [17] - MASTER level control
- [18] - 3-mode switch for high-frequency tone shape: BRIGHT-NORMAL-DARK
- [19] - DRIVE control
- [20] - BASS control
- [21] - MIDDLE control
- [22] - MID-RANGE switch - changes range of MIDDLE control parameters.
- [23] - TREBLE control
- [24] - VOLUME control
- [25] - GAIN control for channel-1
- [26] - BRIGHT tone switch for channel-1
- [27] - BOOST footswitch
- [28] - Fotswitches for channel selection
- [29] - MUTE footswitch

