


Amplification Taurus

Stomp-Head²



- [1] - INPUT
- [2] - Effect-loop SEND
- [3] - Effect-loop RETURN / PA input
- [4] - LINE OUTPUT with speaker cabinet simulation
- [5] - Speakers output / impedance: 4-8-16ohm [auto detect. impedance]
- [6] - BASS control
- [7] - MIDDLE control
- [8] - REVERB control.
- [9] - TREBLE control
- [10] - DRIVE control
- [11] - PRESENCE control
- [12] - REVERB control.
- [13] - VOLUME control
- [14] - Power selector: 50Watt/25Watt
- [15] - LED indicator of the selected channel
- [16] - MUTE foot-switch
- [17] - REVER foot-switch
- [18] - AC POWER input. Range: 90-260V / 50-60Hz
- [19] - FUSE 2A
- [20] - POWER on/off switch

